


Tools Required: 5 mm Allen key.

Supplied Parts



- a | Allen bolt
- b | Washer
- c | Rubber shims x 2



ASSEMBLE CARRIER TO BIKE

1. With Allen key loosen clamp bolt on carrier and open clamp. (Loosen bolt only enough to unfasten hinged clamp – it is unnecessary to completely unscrew bolt). Lightly grease bolt.
2. Position clamp on lowermost section of seatpost – directly on end of seat tube. Close clamp.
3. Depending on diameter of your seatpost, you may need to insert one or both of the supplied rubber sizing shims to achieve a tight, secure fit. Insert shim/s between clamp and seatpost. If shim has one rough surface, that should face seatpost (see fig. 1).
4. Align carrier lengthways with bicycle frame, tighten Allen bolts very firmly (see fig. 2).

IB-RA11 is length adjustable (see fig. 3). This function is useful, for example, if your bag is too close to rear of your seat. To adjust, use a 3 mm Allen key. 1. Unscrew three Allen bolts on top of carrier. 2. Slide carrier frame along carrier shaft to reposition. 3. Retighten bolts firmly.



Carrier must be horizontal.
IB-RA11 is length adjustable.

Warning

1. Do not attach carrier to carbon fibre seatposts.
2. Max. load 10 kg (22 lb).
3. Do not carry people on carrier.
4. Do not use for off-road riding.
5. Ensure PakRak or other bags are securely attached to carrier before using.
6. Ensure all bolts are tight before each use.

警告 (繁體中文) - 中管型貨架

- 1、本產品不可以使用在Carbon碳纖維座管上 2、最大載重10公斤(22磅) 3、本產品不可以載人 4、本產品不適合越野騎行使用
- 5、本產品配合包包使用時請注意包包需牢固組裝在上面 6、每次使用前請確認所有的螺絲必須鎖緊。

警告 (簡體中文) - 中管型貨架

- 1、本產品不可以使用在Carbon碳纤维座管上 2、最大載重10公斤(22磅) 3、本產品不可以載人 4、本產品不適合越野騎行使用
- 5、本產品配合包包使用時請注意包包需牢固組裝在上面 6、每次使用前請確認所有的螺絲必須鎖緊。

Limited Warranty

Ibera warrants this product for normal usage against workmanship, and material defects to the original purchaser for two year from purchase date. Products purchased online are not covered by this warranty unless purchased from an authorised Ibera online store. 1. User assumes all risk of personal injury, damage to or failure of the product when it is used in jumping, acrobatics or similar activities. 2. Warranty does not cover any incidental or consequential damages, such as personal injury or other losses due to accident, neglect, misuse, abuse, modification, normal wear and tear, improper care and cleaning, or failure to follow included instructions.

See other Ibera products at www.ibera.info

Ibera Co. Ltd.

Specifications subject to change without notice. Ibera is a trademark of Ibera Co. Ltd. All other trademarks are property of their respective owners. Copyright 2016 Ibera Co. Ltd. Made in Taiwan. Artwork: 5-2016.